# AND9321/D

# **AX-SIGFOX: Sigfox® Compliant Reference Design**



## ON Semiconductor®

www.onsemi.com

# APPLICATION NOTE

## **About Sigfox**

INTRODUCTION

In the Internet of Things, the domain of nationwide coverage and ultra-low power consumption for smallest amounts of data cannot be addressed by established standards such as GPRS or LTE. This void is now filled by Sigfox, the ultra-low power cellular connectivity solution. It combines a low cost and simple approach together with ultra-low power consumption (see examples of battery life in the AX-Sigfox datasheet).

#### **About the Chips**

This application note describes the ON Semiconductor SIGFOX reference design. The ON Semiconductor SIGFOX chip is available in two versions: AX-SFEU and AX-SFEU-API. The chips add Sigfox functionality for up-link and down-link to any existing system at the cost of  $20 \times 13 \text{ mm}^2 \text{ PCB}$  area. They can also be used as single chip solutions that control small sensor nodes. The AX-SFEU

device is fully programmed for immediate operation as a Sigfox node, while the AX-SFEU chip addresses applications where the user wants to add additional software or wants control over the whole MCU.

#### **AX-SFEU**

AX-SFEU is delivered fully ready and contains all the necessary firmware to transmit and receive data from the SIGFOX network. It connects to the customer product using a logic level RS232 UART. AT Commands are used to send frames and configure radio parameters. The commands adhere to SIGFOX AT Command Specification 0.7 (PRS-UNBT AT CMD).




Figure 1.

AX-SFEU is already SIGFOX ready certified for end products. If the reference design and BOM are followed exactly, no other certification from SIGFOX is required. EN300220 compliance checking is required.

#### AX-SFEU-API

AX-SFEU-API is not delivered with any firmware. The Sigfox protocol library needs to be purchased. This version is ideal for customers who do not want another microcontroller in their product, but instead want to

implement product functionality on the AX-SFEU-API chip. AX-SFEU-API is SIGFOX ready certified for end products. If the reference design, BOM and AX-SFEU documentation are followed exactly, no other certification from SIGFOX is required. EN300220 compliance checking

The API of the library corresponds to the SIGFOX API. On guidance or help on how to setup and program the chip, please refer to the AX-Sigfox Software Manual.

### AND9321/D

#### REFERENCE DESIGN

Eagle and Gerber files of the reference design as well as PDF-files of both the schematic and the layout are part of this application note. A list of the components for the reference design is also provided. With this information, it is possible to recreate the reference design.

The layout is 20 mm  $\times$  13 mm. The antenna output is on the left side of the board. A 50  $\Omega$  antenna with a center frequency of 869 MHz must be connected.

The connection to the host microcontroller and the power supply is located on the right side of the board. The module

must be supplied with a DC voltage in the range of 1.8 V to 3.6 V as specified in the datasheet. A peak current of 50 mA during transmit at maximum power must be provided.

Several test points for additional signals are available in the reference design. The chip supports up to 4 status LEDs for radio activity, CPU activity, transmit and receive. LEDs must be connected to ground via a series resistor (around 220 Ohm). There are also 10 GPIO signals that can be queried and set using AT commands. Please refer to the AX–Sigfox Datasheet for the pin table.

#### **COMMAND INTERFACE**

Serial Parameters: 9600, 8, N, 1

The module uses UART0 to communicate with a host and uses a bitrate of 9600 baud, no parity, 8 data bits and one stop bit.

#### **Power Modes**

To conserve power, the module can be put into sleep or turned off completely.

#### Sleep

Use the command AT\$P=1 to put the module into sleep. In this mode, only the wakeup timer of out-of-band messages is still running. To wake up the module again, toggle the serial RX pin, e.g. by sending a break.

We recommend using sleep mode when you don't need the module. This means: Wake the module up when a message needs to be sent and after transmission, send it back to sleep. If the module remains in standby (0.5 mA) optimal overall power consumption cannot be achieved.

#### Deep Sleep

In Deep Sleep, the module is completely turned off and only draws negligible leakage current. Deep Sleep can be activated with the command AT\$P=2. Pull GPIO9 to ground to wake up the module again.

When using this state, please keep in mind that:

- Everything is turned off, timers are not running are all and all settings will be lost (They can be saved to flash however with the command AT\$WR). Out-of-band messages will therefore not be sent.
- The pins are frozen in deep sleep and will output 1 or 0 constantly. Ensure that this will not result in a condition of the application which would draw a lot of current. External pull-ups or -downs can also consume power.

## AT COMMANDS

#### **Numeric Syntax**

```
\begin{array}{lll} \text{hexdigit} & ::= [0 - 9 A - F a - f] \\ \text{hexnum} & ::= "0x" \text{ hexdigit+} \\ \text{decnum} & ::= "0" \mid [1 - 9] [0 - 9]* \\ \text{octnum} & ::= "0" [0 - 7] + \\ \text{binnum} & ::= "0b" [01] + \\ \text{bit} & ::= [01] \\ \text{optnum} & ::= "-1" \\ \text{frame} & ::= (\text{hexdigit hexdigit}) + \\ \text{uint} & ::= \text{hexnum} \mid \text{decnum} \mid \text{octnum} \mid \text{binnum} \\ \text{uint\_opt} & ::= \text{uint} \mid \text{optnum} \end{array}
```

#### **Command Syntax**

A command starts with 'AT' (everything is case sensitive!), continues with the actual command followed by parameters (if any) and ends with any kind of whitespace (space, tab, newline etc.)

If incorrect syntax is detected ("parsing error") all input is ignored up until the next whitespace character.

Also note that any number can be entered in any format (Hexadecimal, Decimal, Octal and Binary) by adding the corresponding prefix ('0x', '0', '0b'). The only exception is the 'Send Frame' command (AT\$SF) which expects a list of hexadecimal digits without any prefix. For a complete list of available AT Commands and possible examples, please refer to the AX–Sigfox Datasheet.

#### **Return Codes**

A successful command execution is indicated by sending 'OK'. If a command returns a value (e.g. by querying a register) only the value is returned.

## AND9321/D

Sigfox and Sigfox Ready are registered trademarks of Sigfox SARL.

ON Semiconductor and the interpretability are registered trademarks of Semiconductor Components Industries, LLC (SCILLC) or its subsidiaries in the United States and/or other countries. SCILLC owns the rights to a number of patents, trademarks, copyrights, trade secrets, and other intellectual property. A listing of SCILLC's product/patent coverage may be accessed at www.onsemi.com/site/pdf/Patent-Marking.pdf. SCILLC reserves the right to make changes without further notice to any products herein. SCILLC makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does SCILLC assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. "Typical" parameters which may be provided in SCILLC data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals" must be validated for each customer application by customer's technical experts. SCILLC does not convey any license under its patent rights nor the rights of others. SCILLC products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the SCILLC product could create a situation where personal injury or death may occur. Should Buyer purchase or use SCILLC products for any such unintended or unauthorized application, Buyer shall indemnify and hold SCILLC and its officers, employees, subsidiaries, affliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that SCILLC was negl

#### **PUBLICATION ORDERING INFORMATION**

#### LITERATURE FULFILLMENT:

Literature Distribution Center for ON Semiconductor 19521 E. 32nd Pkwy, Aurora, Colorado 80011 USA Phone: 303-675-2175 or 800-344-3860 Toll Free USA/Canada Fax: 303-675-2176 or 800-344-3867 Toll Free USA/Canada Email: orderlit@onsemi.com N. American Technical Support: 800-282-9855 Toll Free USA/Canada Europe, Middle East and Africa Technical Support:

Europe, Middle East and Africa Technical Support: Phone: 421 33 790 2910 Japan Customer Focus Center Phone: 81-3-5817-1050 ON Semiconductor Website: www.onsemi.com

Order Literature: http://www.onsemi.com/orderlit

For additional information, please contact your local Sales Representative